

LG VX4650 – VOICE COMMAND PHONE

VOICE/AUDIO

- Speaker-Independent Voice Recognition – make calls and access other essential features
- Voice Commands: Call Someone, Voice Mail, Digit Dial, Service Alerts, Missed Calls, Contacts, Driving, Announce, Time and Date, Phone Status
- Driving Mode – activates speakerphone and voice commands for safe, hands-free operation
- Powerful Speakerphone
- Polyphonic Ringer and Sound Capability (CMX MIDI Format)
- 36 Unique Default Ringtones
- Manner (Vibrate) and Silent Modes
- TTY/TDD Capable

MOBILE MEDIA

- Mobile Web 2.0 –enhanced online access*
- Get It Now® Capable
- Two-Way Short Messaging Service (SMS)*
- Enhanced Messaging Service (EMS)
- Media Folder – store downloaded pictures, sounds, graphics, animations and more

TOOLS & DATA

- Personal Organizer: Calendar with Scheduler, Voice Memo (up to 4 minutes), Notepad
- Tools: Alarm Clock, My Shortcut, Ez Tip Calc, Calculator, World Clock
- Address Book with 499 Contacts – each stores 5 numbers and 3 e-mail addresses
- Speed Dialing (98 Entries + 1 Default for Voice Mail)

GENERAL

- Mid Tier
- Full-Color Internal LCD
- External Backlit LCD
- Blue Backlit Keypad
- 5-Way Navigation Key
- Customizable Display Options: Banner, Backlight, Wallpaper, Menu Style, Contrast, Fonts and Language

SPECIFICATIONS

- Tri-Mode 1.9 GHz CDMA PCS | 800 MHz CDMA/AMPS
- Dimensions: 3.80" x 1.93" x 0.89"
- Weight: 3.70 ounces
- Internal LCD: 65K Color STN, 128 x 128 Pixels
- External LCD: Monochrome STN, 96 x 64 Pixels
- Battery: 1,000 mAh Li-Ion
- Usage Time: Up to 190 Minutes (Digital)
- Standby Time: Up to 190 Hours (Digital)

The Wireless Devices team introduces the LG VX4650 to the product line-up. Launch date is dependent upon sell thru of the LG VX4500.

Compact Color Phone with Advanced Voice Recognition

When it comes to style and functionality, the VX4650 is second to none. This hot little flip features a powerful speakerphone, full-color internal LCD, and enhanced web services.

You know you'll be looking good, but you'll feel even better with the safety and convenience of Voice Command and Driving Mode.



Product Codes

DYMAX/UPC	Mock-up	VISION
LG-VX4650/652 810812627	LG-VX4650DP	3614



Each VX4650 is packaged with:

- Standard Lithium-Ion Battery (1,000 mAh)
- AC Travel Charger
- User Guide
- Quick Reference Guide
- Welcome CD

** Holster and/or case sold separately

LG VX4650 Optional Accessories

Vehicle Power Charger

LGVPC-2



(Compatible with
VX3200/4700/7000/
6100/8000)

Travel Charger - In Box

LGTVL-2



(Compatible with
VX3200/4700/7000/
6100/8000)

Standard LiIon Battery (1000mAh) - In Box

LGBAT-1



(Compatible with
VX3200/4700/6100)

Extended LiIon Battery w/battery door (1700mAh)

LG4700BATX



(Compatible with VX4700)

Leather Case

LG4700CAS



(Compatible with VX4700)

Swivel Holster

LG4700HOL



(Compatible with VX4700)

Pre-Package Essential Pack

PROM4700COM



Compatible with VX4700)

Hands-Free VPC

LGVXPHF-1



VX3200/4700/7000/
6100/8000)

Battery Wall Charger

LGBATPK-1



(Compatible with
VX3200/4700/6100)
DFILL ONLY

Support Tools

Launch Kits

LG will send Launch Kits to all Verizon Wireless Direct locations the week of **May 16th**.

Launch kits contain one mock-up unit and a pack of reference cards. Store locations may use the **VX4650** mock-up units to merchandise the floor once they sell thru their VX4500s.

If your location does not receive a Launch Kit, please contact your Area Merchandising Manager for a replacement kit.

Store locations may use the literature, product sheets, accessory brochures, data brochures, and other training materials internally. Manufacturer's literature should not be displayed or presented to customers.

Merchandising

Call out cards for the VX4650 will be in the collateral warehouses on May 16th. Please check with your Area Merchandising Contacts if you need additional cards. To view an adobe Acrobat file of the VX4650 Call out card, click on the call out card link in the equipment site:

Product Training

Should you require any product training or support, please contact the LG Corporation Account Manager for your Area.

NE Area

Teresa Cangialosi (201) 988-3325

Ken Bagwell (919) 779-1504

MW Area

Jim Grothjan (513) 245-2027

Chris Diggory (773) 348-0258

South Area

Michael Rickert (772) 784-8190

Frank Graham (713) 252-5442

West Area

Bill Vlahandreas (707) 537-7888

Jim Lake (858) 735-5341

Helpful Hints

Manually Programming the VX4650

1. Press "menu" + 0 and press "000000"
2. Press "1" key for Service Programming
3. Press "ok" (Read only)
4. Input the "Phone number (MDN)" and press "ok"
5. Input the "Phone number (MIN)" and press "ok"
6. Input the "NAM1 Home SID" and press "ok"
7. Input the "NAM1 Name" and press "ok"
8. Confirmation "Basic NAM1 is completed" when programmed successfully
9. Press Left Soft Key for "Exit". Powering Down will proceed

OTA Instructions

1. Perform the usual billing system activation procedure
2. Power up the phone and enter the Star Code, *228 + [send], on the handset
3. The following audio message will be heard:
"Welcome to Verizon Wireless' Over the Air programming. This call is airtime free. Press '1' to program your phone. Press '2' to update your roaming capabilities."

Note: Programming will take up to 2 minutes. Should the programming exceed 45 seconds, the following audio message will be repeated at 25-second intervals: "Please continue to hold. Your phone is being programmed."

You will hear an audio message once the phone has been successfully programmed

How to Access the Web

1. Press left on the Navigation Key to access the web browser.
2. Once the web browser is launched, you will see the Home Page.
3. You can end a browser session by pressing **END** at any time.

IP Address Programming

1. Press "menu" + 0 and enter service code "000000"
2. Press 9 for "WAP Setting"
3. 6 Items will be displayed on the LCD screen
4. Press 1 for "Proxy Address Setting"
5. Press 2 for "Proxy Port Setting"
6. Press 3 for "User Password"
7. Press 4 for "Homepage"
8. Press 5 for "Clear Perm Mem"
9. Press 6 for "Reset Browser"

How to Send a Text Message

1. Press **down** on the Navigation Key and select **New Message (2)**
2. Press **Left Soft Key** for **Contacts** to enter a recipient from the **Contacts (1), Recent Calls (2), or Recent Addresses (3)** menu or use the key pad to enter a new e-mail address or phone number and press **OK**. Up to 10 recipients can be added.
3. Scroll down and enter the message (up to 160 characters) using the keypad and press **Left Soft Key** for **Send**.

How to View the Software, PRL, ERI and Browser Version:

1. From the **Settings (9)** menu, select **Phone Info (8)**
2. Select **S/W Version (2)**

Features/Advantages/Operation of the VX4650

Features	Advantage	Operation
Enhanced Messaging Service (EMS)	Send and receive text messages with graphics and sounds.	1. From standby mode, press the Messages icon (down) on the Navigation Key and select New Message (2). 2. Press Left Soft Key for Contacts to enter a recipient from the Contacts (1), Recent Calls (2) or Recent Addresses (3) menu, or use the keypad to enter a new e-mail address or phone number. Up to 10 recipients can be added. 3. Select Message and press OK. 4. Enter the message (up to 160 characters) using the keypad and press OK. 5. Press Left Soft Key for Send.
Speaker-Independent Voice Recognition (Voice Commands)	Make calls and access other essential features by voice.	1. Press the side Voice Command Key. 2. Say a command: call someone (calls a contact in your phone book), voice mail (calls voice mail), digit dial (dials a phone number by speaking the digits), service alerts (checks missed calls, voice mails or new messages), missed calls (checks missed calls), contacts (reads, creates or erases a contact), driving (activates Driving Mode), announce (turns on audio confirmation of menu navigation), time and date (announces current time and date), phone status (announces status of battery usage, signal strength, service mode, GPS location and roaming)
Speakerphone	For safe, hands-free operation.	1. From standby mode, press the side Speakerphone Key, and "Speaker On" will appear on the screen. 2. Press the side Speakerphone Key again to turn off speakerphone.
Mobile Web 2.0	Customizable, enhanced online access.	From the main screen, press the Web icon (left) on the Navigation Key.
Get It Now 	Grants access to games applications, and special features.	While in standby mode, press the Get It Now icon (right) on the Navigation Key to quickly access the GET It Now menu.